

GM No Drill Kit A036

This No Drill Kit is used in place of the 2 standard end plates included with the A050 Cody Hitch.

3 - (D087) 1/2"x 1 1/2" Grade 8 Bolts & 4 - (D060) 1/2" Top Lock Nuts from the A050 Hitch Bolt Bag are used to secure the Side Plates in this No Drill Kit.

Quantity	Part #	Part	Use
1	AD143	RH Side Plate	End plate to secure hitch
1	AD145	LH Side Plate	End plate to secure hitch
3	AD150	2" Heavy duty washers	Secure Side Plates to truck frame (Both Right and Left Rear)
1	AW048	Bolt bar	Secure front of left Side Plate
1	—	Angle bracket	To relocate Electric Brake Controller from drivers side rear mounting hole

Brake Controller Mounting Angle Bracket

