

Dodge No Drill Kit AO38

This No Drill Kit is used in place of the 2 standard end plates included with the AO50 Cody Hitch.

4 - (D060) 1/2" Top Lock Nuts from the A050 Hitch Bolt Bag are used for securing the U-bolts in this No Drill Kit.

U-Bolt End of Side Plates are installed toward the front of the truck with the Angle Tab secured to the vertical hole through the truck frame, just ahead of the rear axle.

Quantity	Part #	Part	Use
1	AW049L	RH Side Plate	End plate to secure hitch
1	AW049R	LH Side Plate	End plate to secure hitch
2	AD213	U-Bolts	Secure Side Plates to truck frame
2	D091	1/2" Flat washers	Lower slotted Side Plate securing holes
2	D008	7 1/2" x 1/2" bolts	Secure Side Plate Angle Tab to frame
2	AD150	2" washers	Top of frame—7 1/2" bolts
2	D060	1/2" Top lock nuts	Angle Tab 7 1/2" bolts