

# Ford F150 No Drill Kit AO44

This No Drill Kit is used in place of the 2 standard end plates included with the AO50 Cody Hitch.

4 - (D060) 1/2" Top Lock Nuts from the A050 Hitch Bolt Bag are used for securing the Clamp Bars in this No Drill Kit in addition to the hardware included in this kit.

Box brace notch end of Side Plates are installed toward the rear of the truck with the spacer brackets against the lower frame to hold the side plate vertical. Spacer brackets will straddle bump stop support on frame.

Quantity	Part #	Part	Use
1	AW039	LH Side Plate	End plate to secure hitch
1	AW040	RH Side Plate	End plate to secure hitch
4	AD172	Clamp Bar	Secure Side Plates to truck frame
4	D144	4 1/2" x 1/2" Grade 8 bolts	Secure Clamp Bars to Side Plates/Truck Frame. (lower bolts)
4	D145	5" x 1/2" Grade 8 bolts	Secure Clamp Bars to Side Plates/Truck Frame. (upper bolts)
4 in this kit + 4 in hitch bolt bag	D060	1/2" Top lock nuts	Secure Clamp Bars to Side Plates/Truck Frame