

GM 1500 No Drill Kit AO53

This No Drill Kit is used in place of the 2 standard end plates included with the AO50 Cody Hitch. Mounting hardware included with the standard end plates will be used with this no drill kit and is included in this parts list.

Quantity	Part	Use
2	Clamp Plates	End plate to secure hitch to Truck Frame
2	U-Bolts	Secure Clamp Plates to truck frame
2	1/2" Wide area washers	Lower slotted Clamp Plate securing holes
2	1/2" Heavy duty washers	Rear Clamp Plate Attach Bolts
6	1/2" Top lock nuts	U-Bolts & Rear Attach bolts